



RMA-DTAF-SEN

We've got facilities covered.

Monitor air flow and ambient temperature with the Digital Temperature & Air Flow Sensor. Attach this sensor to HVAC ducts, vents and more to be notified in real-time of any changes or variables that could indicate cooling or ventilation problems to could lead to costly downtime or safety issues in your facility. For more information and specifications, please visit AVTECH.com.



